

GSCJ-8301B1 SMT PCB Magazine Loader And Unloader Rack PCB Circuit Board Rack

Basic Information

Place of Origin: ChinaBrand Name: GS

Model Number: GSCJ-8301B1Minimum Order Quantity: 1 PCS

Price: USD+negotiable+pcs
 Packaging Details: 380*350*600mm
 Delivery Time: 1-7 days

Delivery Time: 1-7 orPayment Terms: T/T

• Supply Ability: 1+pcs+per days



Product Specification

• Size: 355 X 320 X 563 Mm

Adjustment Type: Handle
Slot Depth: 3.5 Mm
Slot Width: 5 Mm
Pitch: 10 Mm
PCB Slots: 50

Reference Position: A34 Mm, B34 Mm
Adjustable Width: 35-250 Mm
Side Board Structure: 5 Sheets
Weight: 5.51kg

• Highlight: SMT PCB Magazine, PCB Magazine Rack,

PCB SMT Magazine Rack



More Images



Product Description

Installation Guide

- 1. Install the Rack: Ensure the rack is aligned and flush with the base plate.
- 2. Secure the Columns: Use screws to fix the four columns firmly.
- 3. Attach the Side Panel: Align the holes and tighten the screws.
- 4. Position the Movable Side Panel: Ensure the bottom edge is close to the rack.
- 5. Install the Base Plate: Push the circular pin of the latch upward and move the side panel.
- 6. Install the Stopper: Attach it at the spring position, facing downward.

Special Note: Pay attention to steps 4 and 5. The circular pin of the latch must align precisely with the circular hole on the base plate. Accurate positioning is crucial to avoid misalignment; ensure synchronization in all directions.



GSCJ-8301B1 SMT Loader and Unloader Rack, PCB Board SMT Material Frame, Circuit Board Rack for Material Handling Cart | GSSMT, PCB Magazine Loader, PCB Magazine Rack, SMT PCB Magazine, PCB Magazine Unloader, PCB Magazine Handling, PCB Magazine Storage, PCB Magazine Transport, PCB Magazine Capacity, PCB Magazine Holder, PCB Magazine System.





+8613728696610



liyi@gs-smt.com



smtmachinepart.com