



GSCJ-8301B1-5 Automatic PCB Magazine Loader with Handle Adjustment and Plate Metal Base for 355 x 500 x 563 mm Storage

Our Product Introduction

for more products please visit us on smtmachinepart.com

Basic Information

- Place of Origin: China
- Brand Name: GS
- Model Number: GSCJ-8301B1-5
- Minimum Order Quantity: 1 PCS
- Price: USD+negotiable+pcs
- Packaging Details: 380*520*580mm
- Delivery Time: 1-7 days
- Payment Terms: T/T
- Supply Ability: 1+pcs+per days



Product Specification

- Size: 355 X 500 X 563 Mm
- Adjustment Method: Handle
- Base Material: Plate Metal
- Reference Position: A34 Mm, B34 Mm
- Side Board Structure: 5 Sheets
- Lead Time: 1-7 Days
- Highlight: Automatic PCB Magazine Loader, Automatic PCB Magazine Unloader, GSCJ-8301B1-5 Automatic PCB Loader



More Images



Product Description

GSCJ-8301B1-5 PCB Magazine Loader And Unloader Rack Automatic PCB Loader

GSCJ-8301B1-5 Loading and Unloading Rack for PCBs - Automatic PCB Loader with Storage and Transfer Frame for Circuit Boards and Substrate Boxes

GSSMT, PCB Magazine Loader, PCB Magazine Rack, SMT PCB Magazine, PCB Magazine Unloader, PCB Magazine Handling, PCB Magazine Storage, PCB Magazine Transport, PCB Magazine Capacity, PCB Magazine Holder, PCB Magazine System

Installation Guide

1. Install the Rack: Ensure the rack is aligned and flush with the base plate.
2. Secure the Columns: Use screws to fix the four columns firmly.
3. Attach the Side Panel: Align the holes and tighten the screws.
4. Position the Movable Side Panel: Ensure the bottom edge is close to the rack.
5. Install the Base Plate: Push the circular pin of the latch upward and move the side panel.
6. Install the Stopper: Attach it at the spring position, facing downward.

Special Installation Note

Pay attention to steps 4 and 5. The circular pin of the latch must align precisely with the circular hole on the base plate. Accurate positioning is crucial to avoid misalignment; ensure synchronization in all directions.



Global Soul Limited



+8613728696610



liyi@gs-smt.com



smtmachinepart.com

Room F3B-016, B Block, Hao Yun Lai Business Building, Liutang road, Bao'an District, Shenzhen, China