

SMT Loading And Unloading Rack 460*400*563mm

Our Product Introduction

Basic Information

- Place of Origin: China
- Brand Name: GS
- Model Number: GS460400563
- Minimum Order Quantity: 1 PCS
- Price: USD+negotiable+pcs
- Packaging Details: 500*150*600mm
- Delivery Time: 1-7 days
- Payment Terms: T/T
- Supply Ability: 1+pcs+per days




Product Specification

- Product Name: SMT Loading And Unloading Rack
- Product Specifications: 460*400*563mm
- Adjustable Range: 460*(50 - 330)mm
- Reference Positions: A 34mm, B 34mm
- Product Material: PP Side Panel. Galvanized Upper And Lower Base Plates
- Side Panel Slot Width: 5mm
- Side Panel Slot Depth: 3mm
- Side Panel Structure: 5 Pieces Assembled
- Slot Spacing/Number: 10mm / 50 PCS
- Condition: New

Product Description

SMT Loading And Unloading Rack 460*400*563mm Product Image:





Product Installation Steps:

1. Take out the accessories and check if they are all present.
2. Press down the gear bar firmly.
3. Secure the four vertical columns with screws.
4. Align the side plates with the holes and tighten the screws.
5. Align the bottom of the movable side plate with the circular holes of the clips.
6. Install the base plate, push the round heads of the clips upwards and then move it.
7. Install the stopper on the spring part downwards, and the installation is complete.



Global Soul Limited

+8613728696610

liyi@gs-smt.com

smtmachinepart.com

Room F3B-016, B Block, Hao Yun Lai Bussiness Building, Liutang road , Bao'an District , Shenzhen, China